

Instruction Manual Bogie

The main feature of the Bogie is the movement of the camera 45° left and right, whereby the optic always stays in the center point axis which enables a lot of new framings.

The design is based on stable and save operation with Film and Videokameras.

At the lower side of the Bogie are 5, 3/8" threads, where you can attach a camera plate to mount the Bogie on any head. Put the camera on the upper site of the Bogie by using a touch & go camera plate.

No. 1 is the lock for the touch & go plate and moves from right to left. Please check if the camera is locked.

After you have put on the lens, you have the possibility to adjust/balance the camera. This you can do by using handle no. 4.

Open handle no. 3 and you are free to adjust however you wish your position to be by using no. 2. Have you found your right position, please kindly lock it by using no. 3 again.

If the locking is not good enough, you can pull out no. 3 and set up a new, better angled locking.

We wish you a creative work and good fun with our equipment.

Should you have any question or need any other information please feel free to contact us.

